

Vanguard® AC Marker Installation

The following guide will provide installation steps for the AC version of the Vanguard marker.

1. Open the access plate by loosening the (2) captive screws enough to swing the cover open and remove the installed wire nuts.



2. Feed the marker cable through the black cord grip and strip approximately 1/4" from the jacket of each conductor.



3. Using the supplied wire nuts and electrical tape connect the (2) Black wires, the (2) White wires, and the (2) Green wires together.



4. Carefully place the wires inside the marker base and close the access plate. Ensure the screws and the cord grip are tight to prevent moisture intrusion.

