

Wi-Fi USB Interface Guide



USB Port

1) With the Vanguard system powered on, insert the USB Wi-Fi into the USB port on the SMART board directly above the main power supply.

2) On your Wi-fi enabled device, if Wi-Fi is not currently on, go to settings and turn on Wi-Fi.

3) In Wi-Fi Settings select the Wi-Fi signal titled:

Vanguard USB

4) Enter password. The password is CASE SENSITIVE.

Password: **FlashAdmin** (no spaces)

5) Once connected, open the device's browser. Enter in the following address to connect to the Vanguard:

192.168.2.11

6) When you are done using the USB Wi-Fi, it is recommended to remove the USB for security and operational protection.

Wi-Fi USB Interface Guide



USB Port

1) With the Vanguard system powered on, insert the USB Wi-Fi into the USB port on the SMART board directly above the main power supply.

2) On your Wi-fi enabled device, if Wi-Fi is not currently on, go to settings and turn on Wi-Fi.

3) In Wi-Fi Settings select the Wi-Fi signal titled:

Vanguard USB

4) Enter password. The password is CASE SENSITIVE.

Password: **FlashAdmin** (no spaces)

5) Once connected, open the device's browser. Enter in the following address to connect to the Vanguard:

192.168.2.11

6) When you are done using the USB Wi-Fi, it is recommended to remove the USB for security and operational protection.